

Manual RetroTVClock



Thank you for getting yourself a RetroTVClock! With this product you support circularity of plastics. See more on www.san-designs.com 😊
Support us also by following on Instagram: www.instagram.com/studio.san.designs

The clock requires a AA battery to operate.



!! BE CAREFUL WITH THE LEGS AND ANTENNA THEY ARE VERY FRAGILE !!

Should a leg or antenna break off, it is possible to replace it. Contact for spare parts (short leg/long leg/antenna) Drill the hole 3mm where it broke off. Glue the replacement part back together with second glue. DONE!!! Contact at hello@san-designs.com

Adjusting time:

<p>1. Lift and remove the backcover by putting your finger in the hole and pulling gently.</p>	
<p>2. Rotate the right wheel of the hourwork until the right time is set.</p>	
<p>3. Put the right edge of the backplate in place first.</p>	
<p>4. Lower the left edge of the backplate and push gently until you're satisfied.</p>	

(Re)placing the battery:

<p>1. Lift and remove the backcover by putting your finger in the hole and pulling gently.</p>	
<p>2. Gently push the hourwork a bit backwards.</p>	
<p>3. Remove the battery cover by lifting it on the lower side (it is not required to have the battery cover back in place again, it can work without).</p>	
<p>4. Replace the battery.</p>	
<p>5. Push the hourwork to the front again.</p>	
<p>6. Put the right edge of the backplate in place first.</p>	
<p>7. Lower the left edge of the backplate and push gently until you're satisfied.</p>	